



NOTES: IF ANY PORTION OF THE MEMBRANE FLASHING DETAIL IS TO BE LEFT EXPOSED, FLEX-FLASH UN MUST BE INSTALLED IN BONDING ADHESIVE (DETAIL LEFT). MM 6125-FR MAY BE EXTENDED AS THE FLASHING WHEN THE DETAIL IS TO BE COMPLETELY COVERED (DETAIL RIGHT).

FLEX-FLASH F MAY BE USED AT ALL CONCRETE-TO-CONCRETE AND CONCRETE-TO-CONCRETE BLOCK TRANSITIONS. FLEX-FLASH UN MUST BE USED AT ALL OTHER TRANSITIONS (i.e., CONC.-TO-GYP. BOARD, GYP. BOARD-TO-GYP. BOARD, ETC.).

REFERENCE GUIDELINE DETAIL R-12 FOR ALTERNATE CORNER TRANSITION DETAILS.



Monolithic
Membrane
6125-FR
ROOFING SYSTEMS

AMERICAN HYDROTECH, INC.

TYPICAL TIE-IN DETAILS
(THRU-WALL/AIR BARRIER)

NO SCALE

R-17C