



NOTES:

1. AREA AROUND DRAIN SHOULD BE DEPRESSED/SUMPED TO PROMOTE POSITIVE WATER DRAINAGE.
2. SURFACE PREP OF DRAIN BOWL SHOULD EXTEND $\frac{1}{8}$ " MAX. BEYOND FLASHING TERMINATION POINT.
3. HYDROSEAL FLASHING RESIN AND FLEECE SHOULD EXTEND A MINIMUM 2" INTO PROPERLY PREPARED DRAIN BOWL.
4. ALL HYDROSEAL FLEECE, INCLUDING OVERLAPS, MUST BE SET IN AND COVERED OVER WITH HYDROSEAL RESIN.



HydroSeal
Deck Membrane

AMERICAN HYDROTECH, INC.

TYPICAL DRAIN DETAIL

SCALE: NONE
DATE: 07/19

HS-9