



NOTES:

1. APPLICATION OF APPROPRIATE HYDROSEAL PRIMER MUST PRECEDE APPLICATION OF HYDROSEAL FLASHING AND DECK MEMBRANES.
2. ALL HYDROSEAL FLEECE, INCLUDING OVERLAPS, MUST BE SET IN AND COVERED OVER WITH HYDROSEAL RESIN.
3. VARIOUS SURFACING OPTIONS ARE POSSIBLE. REFERENCE DETAILS HS-1A THROUGH HS-2B
4. HYDROSEAL SURFACINGS SHOULD BE HELD BACK 1" MIN. FROM THE SLAB EDGE..



HydroSeal
Deck Membrane

AMERICAN HYDROTECH, INC.

**SLAB EDGE FLASHING FOR
BALCONY, TERRACE, OVERHANG, ETC.**

**SCALE: NONE
DATE: 07/19**

HS-13