



NOTES:

1. APPLICATION OF APPROPRIATE HYDROSEAL PRIMER MUST PRECEDE APPLICATION OF HYDROSEAL FLASHING AND DECK MEMBRANES.
2. ALL HYDROSEAL FLEECE, INCLUDING OVERLAPS, MUST BE SET IN AND COVERED OVER WITH HYDROSEAL RESIN.
3. ALL HYDROSEAL FLEECE SHOULD BE PRE-CUT AND DRY FIT PRIOR TO INSTALLING HYDROSEAL FLASHING RESIN.

HydroSeal
Deck Membrane

AMERICAN HYDROTECH, INC.

**OUTSIDE CORNER
REINFORCEMENT**

| | |
|--|---------------|
| SCALE: NONE DATE: 07/19 | HS-15B |
|--|---------------|

This information is intended only for general conceptual purposes. It is based on data and knowledge considered to be true and correct. It is offered for the user's consideration, investigation and verification and is not intended to substitute for the advice provided by appropriate professionals. Hydrotech assumes no liability for the use of this information. The determination of the suitability and applicability of this information is the sole responsibility of the user.